


Vane Savers

www.FixMyBlinds.com



STEP 1

Center and gently tap the Vane Saver onto the damaged PCV or vinyl vertical blind vane.



STEP 2

Rehang repaired vane.